

Jefa Rudder S Y S T E M S

5T000Z bearing



Instruction for replacing and mounting O-ring Partno: 5T000Z-OR



1) Remove the O-ring from the cover.



2) Clean the bearing house and cover.



3) Grease the cover.



4) Mount the new O-ring on the cover.



5) Grease the bearing before mounting the cover.

Jefa Marine A/S, Nimbusvej 2, 2670 Greve, Denmark

Tel: +45 56155210

fax: +45 56155208

email info@jefa.com

Extended information on Jefa Rudder & Steering system can be found on our website www.jefa.com